

Work Order ID 77481***77481***

Page 1

Wednesday, December 21, 2011 3:51:48 PM

Item ID: D206-781-021

Accept

N900040100Setup Start ***NS1***

Revision ID:

Stop ***NS2***

Item Name: Floor Protector (Passenger Cabin)

Start Date: 12/8/2011 Start Qty: 1.00

1

Cust Item ID:

Required Date: 12/9/2011 Req'd Qty: 1.00

1

Customer: CU-DAR001

Reference: RMA RA111303

Approvals: Process Plan: mf Date: 11-12-21 Tooling: _____ Date: _____Run Start ***NR1***

QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr

Revision Nbr

100

QC5- Inspect part completeness to step on W/O

0.00

100

QC

Memo

0.00

Quality Control

INSPECT RA 111303
D206-781-021 X 1 B 75109

KIT IS COMPLETE

ADD NEW PAPERWORK AND LABELS

S 11/12/26

C

110

0.00

110

Packaging

Memo

0.00

Packaging

ID AND STOCK UNDER NEW BATCH NUMBER

FC 40

11/10/2011

Work Order ID 77481***77481***

Page 2

Wednesday, December 21, 2011 3:51:48 PM

Item ID: D206-781-021

Accept

N900040100Setup Start ***NS1***

Revision ID:

Stop ***NS2***

Item Name: Floor Protector (Passenger Cabin)

Start Date: 12/8/2011 Start Qty: 1.00

1

Cust Item ID:

Required Date: 12/9/2011 Req'd Qty: 1.00

1

Customer: CU-DAR001

Reference: RMA RA111303

Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____

Run Start ***NR1***

QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
120	QC21- Final Inspection - Work Order Release	0.00							
120									
QC	Memo	0.00							
Quality Control									

CK 12/01/02

R11-12-29